




Exhibit Fabric Care



Fabric graphics can be dry cleaned.



Wrinkles can be removed from the fabric with a cool iron or fabric steamer.



Fabric graphics can be washed (low mechanical action is required).



Do not tumble dry. Fabric must be completely dry on the frame to prevent from shrinking.



Do not use bleaching agents in the wash or penultimate rinse which is where the bleach is normally introduced into your washing machine. Care should be taken that undiluted bleach does not touch the clothing or damage to the color and fabric will be permanent and final.

Handling Tips

1. If your exhibit fabric has a zipper attached to it, it is best to zip it closed for storage.
2. Wrinkles can be removed from the fabric with a cool iron or fabric steamer.
3. Fabric should not be stored when damp.

Stain Treatment

1. Try removing stains with water alone. Some cleaning products can leave residue or help set-in the stain.
2. Treat the stain from the backside when possible.
3. Remove as much of the dry stain material as possible using a soft bristled brush and be sure not to rub too hard.
4. Use a clean, lint-free white cloth and lightly pat the stain from the outside moving in to keep the stain from spreading.
5. If a cleaning solution is used, rinse the area with water to ensure no solution is left on the fabric.
6. Most stains can be treated with a household fabric stain remover. It is always important to test how the solution will react to a fabric. This can be accomplished by dabbing the solution on the fabric. Most household cleaners will provide suggested treatments depending on the type of stain.

Washing or Dry Cleaning

1. Your fabric graphics can be washed or dry cleaned. Remove any hardware attached to the fabric prior to cleaning. Be sure to use mild soap, cool water and cool heat to prevent the fabric from shrinking.
2. Fabric must be completely dry prior to storing.